



Soft-Zep

The Reinhardt Soft-Zep is nothing short of a revolution in simplicity, design and performance. The Soft-Zep has vastly improved wind noise reduction in comparison with standard basket windshields.

Especially developed so that the microphone can be mounted easily and swiftly with no tricky bayonet or screw fittings to wrestle with, the microphone is simply inserted into the rear of the Soft-Zep just like an ordinary foam windshield.

Weight has been a key factor in the design of the Soft-Zep, weighing in an astoundingly light 385gms or 13.58oz

The hand grip has benefited from the experience that Reinhardt has gathered from the now famous PG2 pistol grip. Made from high quality Kraton rubber with extra soft gel in-

serts with a slip-free surface for a secure and comfortable grip.

The 3/8 whitworth boom-pole mount is offset and can be swivelled and then locked in position for maximum comfort and convenience.

The Soft-Zep is available with three different hole sizes:-

19mm Model **SoftZep19**

22mm Model **SoftZep22**

24mm Model **SoftZep24**

It is recommended that you use the correct size of Soft-Zep for your microphone. Check your microphone diameter and use the Soft-Zep which has a hole size closest to your microphone size. The Soft-Zep hole can be stretched by approximately two millimeters.



Adjusting the Boom Pole Mount.

The boom pole mount can be rotated to a comfortable position and used as a thumb rest. Loosen the 5mm hexagonal screw and rotate to the desired position and retighten. Be careful not over tighten the hexagonal screw.



Adjusting the angle of the Pistol Grip.

The angle of the pistol grip can be adjusted for optimum comfort or it can also be folded flat so that the Soft-Zep can be placed in a kit bag. The angle of the handle can be adjusted using the small lever. The lever can be placed in a convenient position by pressing the button and lifting the lever so that it can be rotated to the desired position.

Optional Fur Windsock.

Part number: ZEP110-400. The windsock is extremely easy to fit if you follow these simple instructions.

1. To fit the windsock roll back the fur about half way.
2. Gently Pull on the fur cover.
3. Carefully pull the lining of the cover towards the microphone end, so that there is no slack left on the inside of the fur cover
4. 5) Close the metal pop fasteners



Do not remove the foam windshield from the frame unless absolutely necessary.